

Foamer Simpson™

Maintenance



To maintain your Foamer Simpson (single hose model) in optimal condition from time to time it may be necessary to clean out the air intake inside the tank. Debris can build up and clog the intake holes. A clean air intake will ensure your Foamer Simpson produces thick rich foam every time you use it.

1. Unscrew the black tank nut and remove the hose assembly from the tank.



2. Remove the pink drop tube from the red terminus. Insert a paper clip, needle or other piece of metal through both air intake holes in the red terminus to remove debris.

